



EZM-7750 72X72DIN 1/8 Multi-Functional Timer & Counter

- 6 digit actual, 6 digit set display
- Operating with 2 sets
- Reset, pause and ChA-ChB counter inputs
- Selectable NPN/PNP input types
- Programmable Counter/Totalizer Counter, Batch Counter, Timer, Chronometer, Frequncymeter and Tachometer functions
- Programmable time scale (Second, Minute, Hour) for Timer and Chronometer
- Operating with Automatic and Manual Reset
- For counting function, selectable INC, DEC, INC/INC, INC/DEC, UP/DOWN, x1 / x2 / x4 (with encoder) type of counting
- Coefficient and decimal point position
- Programmable alarm functions in Frequncymeter and Tachometer modes.
- Operating by absolute or offset in Counter mode.
- Optional serial communication with MODBUS via RS-232 or RS-485

Instruction Manual

INSTRUCTION MANUAL	1
EU DECLARATION OF CONFORMITY.....	3
1 INTRODUCTION:.....	5
1.1 MODEL CODE:.....	6
2 INSTALLATION:.....	7
2.1 GENERAL DESCRIPTION:.....	7
2.2 DIMENSIONS:.....	8
2.3 PANEL CUT-OUT:.....	8
2.4 ENVIRONMENTAL RATINGS:.....	8
2.5 PANEL MOUNTING:.....	9
2.6 OPERATING FUNCTION SELECTION BY DIP SWITCHES:.....	10
3 ELECTRICAL CONNECTIONS:.....	11
3.1 TERMINAL LAYOUT AND CONNECTION INSTRUCTION:.....	12
3.2 POWER SUPPLY:.....	12
3.3 INPUTS:.....	13
3.4 I/O MODULES INSTALLATION:.....	14
OPERATING MANUAL.....	17
4 FRONT PANEL DESCRIPTION:.....	17
4.1 SET-1 & SET-2 ADJUSTMENTS:.....	18
4.2 OBSERVING AND CHANGING PARAMETER VALUES:.....	18
4.3 PARAMETERS LIST:.....	19
4.4 OUTPUT FUNCTIONS:.....	24
TECHNICAL SPECIFICATIONS:.....	30

CINCINNATI PRECISION MACHINERY 513-860-4133

EU DECLARATION OF CONFORMITY

Manufacturer's Name : EMKO ELEKTRONIK A.S.
Manufacturer's Address : DOSAB, Karanfil Sk., No 6,
16369 Bursa, TURKEY

The manufacturer hereby declares that the product:

Product Name : Programmable Timer & Counter Unit

Model Number : EZM-7750

Type Number : EZM-7750

Product Category : Electrical equipment for measurement,
control and laboratory use

Conforms to the following directives:

73 / 23 / EEC The Low Voltage Directive as amended by 93 / 68 / EEC

89 / 336 / EEC The Electromagnetic Compatibility Directive

has been designed and manufactured to the following specifications:

EN 50081-2 EMC Generic Emission Standard for the Industrial Environment

EN 50082-2 EMC Generic Immunity Standard for the Industrial Environment

EN 61010-1 Safety Requirements for electrical equipment for measurement, control and laboratory use

CINCINNATI PRECISION MACHINERY 513-860-4133

Please read the following information before using and thank you very much for buying Emko' s product.

The safety requirements are classified as either “warning“ and “caution” according to the following explanations:

● **WARNING:** Suggest that the user' s mishandling can results in personal death or serious injury.

● **CAUTION:** Suggest that the user' s mishandling can results in personal injury or damage to the property.

Pack List:

- 1- One piece unit.
- 2- Two pieces fixing clamps.
- 3- One piece “user manual”.

CINCINNATI PRECISION MACHINERY 513-860-4133

1 INTRODUCTION:

EZM series multifunctional counters can be used beside packing machines, production and quality control rollers, in cutting and processing machine of glass, plastic, marble, sheet iron, fabric all measuring and controlling of dimension, count, total count, speed, tachometer, productivity, time and can be adapted easily to all mechanical construction and automation systems.

CINCINNATI PRECISION MACHINERY 513-860-4133

1.1 MODEL CODE:

EZM-7750 (72x72 DIN 1/8)	A	BC	D	E	/	FG	HI	/	U	V	W	Z
		00		0	/			/			0	0

A Supply Voltage	
1	85-264VAC 50/60Hz
2	15 to 30VAC 50/60 Hz, 18 to 36VDC
9	Customer

D Serial Interface	
0	Non
1	RS-232
2	RS-485 (MODBUS)

E Output-1	
0	Non

FG Module-1	
00	Non
01	Relay Output Module
02	SSR Drive Output Module
03	Transistor Output Module

HI Module-2	
00	Non
01	Relay Output Module
02	SSR Drive Output Module
03	Transistor Output Module

U Function of Device	
0	Counter and Totalizer Counter
1	Batch Counter
2	Timer
3	Frequencymeter and Tachometer
4	Chronometer

V Input Type	
0	NPN
1	PNP

CINCINNATI PRECISION MACHINERY 513-860-4133

2 INSTALLATION:

C WARNING:


- 1- A visual inspection of this product for possible damage occurred during shipment is recommended before installation. It is your responsibility to ensure that qualified mechanical and electrical technicians install this product.
- 2- If there is danger of serious accident resulting from a failure or defect in this unit, provide the unit with an appropriate external protective circuit to prevent an accident.
- 3- The unit is normally supplied without a power switch or a fuse. Use power switch and fuse as required (fuse rating is 1A@250VAC)
- 4- Be sure to use the rated power supply voltage to protect the unit against damage and to prevent failure.
- 5- Keep the power off until all of the wiring is completed so that electric shock and trouble with the unit can be prevented.
- 6- Never attempt to disassemble, modify, or repair this unit. Tampering with the unit may results in malfunction, electric shock, or fire.
- 7- Do not use the unit in combustible or explosive gaseous atmospheres.
- 8- During the equipment is putted in hole on the metal panel while mechanical installation some metal burrs can cause injury on hands, you should be careful. Installation parts of equipment should be tighten properly. The equipment can be drop from mounting place reason of vibration if installation parts leave soft.

C WARNING: Before beginning installation of this product:


- Disconnect all electrical power to the machine.
- Make sure the machine cannot operate during installation.
- Follow all safety warnings of the machine manufacturer.

Read and follow all installation instructions.


2.1 General Description:



2.2 Dimensions:



2.3 Panel Cut-Out:



2.4 Environmental Ratings:

Operating Conditions:

Operating temperature	: -5 ... +55°C
Maximum operating humidity	: 90% Rh (non-condensing)
Altitude	: Up to 2000 m.

C CAUTION:

Forbidden Conditions:

Corrosive atmosphere

Explosive atmosphere


Home application (The unit is only for industrial applications)

2.5 Panel Mounting:

Insert To Panel:

⚠ WARNING: During the equipment is putted in hole on the metal panel while mechanical installation some metal burrs can cause injury on hands, you should be careful. Installation parts of equipment should be tighten properly. The equipment can be drop from mounting place reason of vibration if installation parts leave soft.


- 1- Prepare panel cut-out.
- 2- Check front panel gasket position.
- 3- Insert the device trough the cut-out.



Installation Fixing Clamp:


The unit is designed for panel mounting. Fixing is by mounting clamp.

1. Insert the unit in the panel cut-out from the front.
2. Insert the mounting clamp from the rear side of the device and tighten the fixing screws to secure the unit against the panel.




Pulling Fixing Clamp:

- 1- You can unscrew to screws.
- 2- Pull the mounting clamp by screw driver from the front side of the device.
- 3- Pull the unit in the panel cut-out.



2.6 Operating Function Selection by DIP Switches:

CAUTION: You can select to operating function and input type (PNP or NPN) by DIP Switch on the device.



DIP Switches are under the cover and cover is on top side of the device.

Choosing to Function

OFF ON 1 <input type="checkbox"/> <input checked="" type="checkbox"/> 2 <input checked="" type="checkbox"/> <input type="checkbox"/> 3 <input checked="" type="checkbox"/> <input type="checkbox"/>	Counter and Totalizer Counter
OFF ON 1 <input type="checkbox"/> <input checked="" type="checkbox"/> 2 <input checked="" type="checkbox"/> <input type="checkbox"/> 3 <input type="checkbox"/> <input checked="" type="checkbox"/>	Batch Counter
OFF ON 1 <input checked="" type="checkbox"/> <input type="checkbox"/> 2 <input type="checkbox"/> <input checked="" type="checkbox"/> 3 <input type="checkbox"/> <input checked="" type="checkbox"/>	Timer
OFF ON 1 <input type="checkbox"/> <input checked="" type="checkbox"/> 2 <input type="checkbox"/> <input type="checkbox"/> 3 <input checked="" type="checkbox"/> <input type="checkbox"/>	Frequencymeter and Tachometer
OFF ON 1 <input checked="" type="checkbox"/> <input type="checkbox"/> 2 <input type="checkbox"/> <input checked="" type="checkbox"/> 3 <input type="checkbox"/> <input checked="" type="checkbox"/>	Chronometer

Input Type Selection

OFF ON 4 <input checked="" type="checkbox"/> <input type="checkbox"/>	NPN
OFF ON 4 <input type="checkbox"/> <input checked="" type="checkbox"/>	PNP


3 ELECTRICAL CONNECTIONS:

WARNING:

You must ensure that the controller is correctly configured for your application. Incorrect configuration could result in damage to the process being controlled, and/or personal injury. It is your responsibility, as the installer, to ensure that the configuration is correct. The controller may either have been configured when ordered, or may need configuring now.

WARNING:

This equipment does not contain any parts and material related to users. Only qualified personnel and technician trained specially should work on this equipment. This equipment contains dangerous voltage inner circuits for human life. There is severe dangerous for human life on the case of unauthorised intervene.



WARNING:

Before the connecting of module terminals, you must ensure that correct I/O modules installed in the device.


WARNING:







Be sure to use the rated power supply voltage to protect the unit against damage and to prevent failure.

WARNING:


Keep the power off until all of the wiring is completed so that electric shock and trouble with the unit can be prevented.

3.1 Terminal Layout and Connection Instruction:



-  6mm / 0,23in
Wire Size:
18AWG/1mm²
Solid/Stranded
-  12 screw terminal M3
-  Option terminals
-  Empty terminals
-  Holding screw 0,5Nm
-  Screw driver 0,8x3mm

3.2 Power Supply:



Switching power supply with multiple isolation

High voltage version:

85 to 264 V~, frequency 50 / 60Hz.

Low voltage version:


15 to 30 V~, frequency 50 / 60Hz.

18 to 36 V_C*


CINCINNATI PRECISION MANUFACTURING 513-260-7133

3.3 Inputs:


DIP SWITCH SETTING : PNP
Proximity & switch connection




DIP SWITCH SETTING : NPN
Proximity & switch connection




DIP SWITCH SETTING : PNP
Incremental Encoder & switch connection




DIP SWITCH SETTING : NPN
Incremental Encoder & switch connection



DIP SWITCH SETTING : PNP
Switch connection




DIP SWITCH SETTING : NPN
Switch connection



NOTE 1:
Auxiliary power supply for external transmitter
12Vdc $\pm 10\%$ / 50mA max with short circuit protection


3.4 I/O Modules Installation:

1 First, detach all cable connections from the device and uninstall it from the panel




2 Suppress to the lock pins where top and bottom of the device


3 Pull the cover case by your hand through rear side




4 Pull out the cover case from the device




5 Slide input / output modules in to cavity



6 Replace the cover case by taking care of the terminal numbers should be at right orientation.





Module-1 / Module-2 Optional Output Modules





OUTPUT MODULES:

Relay output connection




Relay output connection




C CAUTION:

Make sure the load does not exceed the rated capacity of the relay.

SSR driver output connection




Digital Output Module Connection




SERIAL INTERFACE MODULES:

RS - 232 Serial Communication Interface




RS - 485 Serial Communication Interface



Operating Manual

4 Front Panel Description:




OP1	OP-1 (Output-1) condition watch by this LED as Actual values according to Parameter 14 and SV1 (Set-1) values.
OP2	OP-2 (Output-2) condition watch by this LED as Actual values according to Parameter 15 and SV2 (Set-2) values.
SV1	Set value display, show to SV1 (SET1) value when this LED light.
SV2	Set value display, show to SV2 (SET2) value when this LED light.



	This button is used for changing and observing to value of SV1 (SET1)
	This button is used for changing and observing to value of SV2 (SET2)
	This button is used for entering the program mode.
	This button is used for saving the memory of changed parameter values when the device on program mode.
	This button is used for shifting cursor position on the programming mode and setting of set values.
	It changes the flashing display value, from 0 to 9.
	This button is used for resetting to actual counting value.
	This button is used for displaying the total value on counter.


4.1 Set-1 & Set-2 Adjustments:

Observing and Changing to SET1 values

Press  button. The Set Value Display shows set value of SET1.


When the cursor to become visible as flashing digit on the display, press  button.



You can change to SET1 value by  button for the cursor digit position changing,  button for the cursor digit value changing.


Press  button for saving to memory of SET1 value. When the value saved in memory, the cursor gets lost.

Observing and Changing to SET2 values

Press  button. The Set Value Display shows set value of SET2.


When the cursor to become visible as flashing digit on the display, press  button.

You can change to SET1 value by  button for the cursor digit position changing,  button for the cursor digit value changing

Press  button for saving to memory of SET1 value. When the value saved in memory, the cursor gets lost.



4.2 Observing and changing parameter values:


Entering Program Mode:

You can press  button for entering program mode.

Actual and Set value display show first parameter of determined operating mode when you enter Program mode.

You can select your requested parameter as change value by  button.

You can change to parameter value by  and  buttons.

You can press  button for save in memory of new parameter value.


After process you can press  button for exiting to program mode.


4.3 Protection of Parameters:


You can see Protection Parameter "Pro-PS" to after Parameter-30. Can be adjust to it from "0001" to "9999". If parameter value is "0000", this protection will be disable.


If you adjust to this parameter value is different than zero, when you can entering to programming mode, device will ask you password value and "Psuurd" message will shown on the display.


4.3 Parameters List:

	COUNTER and TOTALIZER COUNTER PARAMETERS:
PRO-01	Input type and function's 0- UP Counting by a rising edge of Ch-A. 1- DOWN Counting by a falling edge of Ch-A. 2- UP Counting by a rising edge of Ch-A and DOWN Counting by a falling edge Ch-B. 3- UP Counting by a rising edge of Ch-A and Ch-B. 4- UP Counting by a rising edge of Ch-A when Ch-B=0. DOWN Counting by a rising edge Ch-A when Ch-B=1. 5- 1 x Incremental encoder counting 6- 2 x Incremental encoder counting 7- 4 x Incremental encoder counting
PRO-04	Contact Bounce for electrical noise. Adjustable from 0 to 250 milliseconds.
PRO-06	Configuration for output functions. Refer to "Output Functions" for detail.
PRO-14	Output Function for module-1 0- Normally non-energised 1- Normally energised
PRO-15	Output Function for module-2 0- Normally non-energised 1- Normally energised
PRO-16	Energising time for Module-1. Adjustable from 0000.00 to 0099.99 seconds. Refer to "Output Functions" for detail.
PRO-17	Energising time for Module-2. Adjustable from 0000.00 to 0099.99 seconds. Refer to "Output Functions" for detail.
PRO-19	Selection counting direction. 0- 0 to PRESET 1- PRESET to 0
PRO-20	Decimal point position of the display. 0- 000000, 1- 00000.0, 2- 0000.00, 3- 000.000, 4 -00.0000
PRO-21	It's determinates, actual value on the display saved or unsaved to memory when the energy breaking. 0- Saved to memory. When the device energised, counting become from saved actual value. 1- Unsaved to memory. When the device energised, counting become from "0".
PRO-22	This parameter determinates, used or not used SV1 value as an OFFSET value. If parameter value is "1", Sv1value is SV2+SV1. 0- Absolute value, 1- Offset value
PRO-23	Slave Address for serial communication bus. Adjustable from 1 to 247. The parameter value is "1" for single device on the serial communication bus.
PRO-24	Configuration for MODBUS protocol. 0- MODBUS protocol is ASCII . 1- MODBUS protocol is RTU (Binary) .
PRO-25	Parity: 0-None, 1-Even, 2-Odd
PRO-26	Baud Rate: 0-1200 Bps, 1-2400 Bps, 2-4800 Bps, 3-9600 Bps, 4-19200 Bps
PRO-27	Stop Bits: 0- 1 Stop bit, 1- 2 Stop bit
PRO-28	Protection for RESET, SET-1 and SET-2 buttons on the front panel. The parameter is adjustable 0 to 5. 0-Non protection. All buttons are active. 1-Only protection for RESET button is active. 2-Protection for SET1 and SET2 buttons are active. 3-Protection for SET1, SET2 and RESET buttons are active. 4-Only protection for SET1 button is active. 5-Only protection for SET2 button is active.
PRO-30	Multiplication factor for input counting. The parameter is adjustable from 01.0000 to 99.9999.

	BATCH COUNTER PARAMETERS:
PRO-01	Input type and function's 0- UP Counting by a rising edge of Ch-A. 1- DOWN Counting by a falling edge of Ch-A. 2- UP Counting by a rising edge of Ch-A and DOWN Counting by a falling edge Ch-B. 3- UP Counting by a rising edge of Ch-A and Ch-B. 4- UP Counting by a rising edge of Ch-A when Ch-B=0. DOWN Counting by a rising edge Ch-A when Ch-B=1. 5- 1 x Incremental encoder counting 6- 2 x Incremental encoder counting 7- 4 x Incremental encoder counting
PRO-04	Contact Bounce for electrical noise. Adjustable from 0 to 250 milliseconds.
PRO-06	Configuration for output functions. Refer to "Output Functions" for detail.
PRO-14	Output Function for module-1 0- Normally non-energised 1- Normally energised
PRO-15	Output Function for module-2 0- Normally non-energised 1- Normally energised
PRO-16	Energising time for Module-1. Adjustable from 0000.00 to 0099.99 seconds. Refer to "Output Functions" for detail.
PRO-17	Energising time for Module-2. Adjustable from 0000.00 to 0099.99 seconds. Refer to "Output Functions" for detail.
PRO-19	Selection counting direction. 0- 0 to PRESET 1- PRESET to 0
PRO-20	Decimal point position of the display. 0- 000000, 1- 00000.0, 2- 0000.00, 3- 000.000, 4 -00.0000
PRO-21	It's determinates, actual value on the display saved or unsaved to memory when the energy breaking. 0- Saved to memory. When the device energised, counting become from saved actual value. 1- Unsaved to memory. When the device energised, counting become from "0".
PRO-23	Slave Address for serial communication bus. Adjustable from 1 to 247. The parameter value is "1" for single device on the serial communication bus.
PRO-24	Configuration for MODBUS protocol. 0- MODBUS protocol is ASCII . 1- MODBUS protocol is RTU (Binary) .
PRO-25	Parity: 0-None, 1-Even, 2-Odd
PRO-26	Baud Rate: 0-1200 Bps, 1-2400 Bps, 2-4800 Bps, 3-9600 Bps, 4-19200 Bps
PRO-27	Stop Bits: 0- 1 Stop bit, 1- 2 Stop bit
PRO-28	Protection for RESET, SET-1 and SET-2 buttons on the front panel. The parameter is adjustable 0 to 5. 0-Non protection. All buttons are active. 1-Only protection for RESET button is active. 2-Protection for SET1 and SET2 buttons are active. 3-Protection for SET1, SET2 and RESET buttons are active. 4-Only protection for SET1 button is active. 5-Only protection for SET2 button is active.
PRO-30	Multiplication factor for input counting. The parameter is adjustable from 01.0000 to 99.9999.

	TIMER PARAMETERS:
PRO-05	This parameter time base for Timer and Counter Mode. 0- From 00 hour 00 minute to 99 hour 59 minutes 1- From 00 minute to 00 second 99 minutes 59 seconds 2- From 00 second 00 milisecond to 99 seconds 99 miliseconds 3- From 00 hour 00 minute to 23 hours 59 minutes 4- From 000.00 hour to 999.99 hours 5- From 000.00 minute to 999.99 minutes 6- From 000.00 second to 999.99 seconds
PRO-06	Configuration for output functions. Refer to "Output Functions" for detail.
PRO-14	Output Function for module-1 0- Normally non-energised 1- Normally energised
PRO-15	Output Function for module-2 0- Normally non-energised 1- Normally energised
PRO-16	Energising time for Module-1. Adjustable from 0000.00 to 0099.99 seconds. Refer to "Output Functions" for detail.
PRO-17	Energising time for Module-2. Adjustable from 0000.00 to 0099.99 seconds. Refer to "Output Functions" for detail.
PRO-19	Selection counting direction. 0- 0 to PRESET 1- PRESET to 0
PRO-21	It's determinates, actual value on the display saved or unsaved to memory when the energy breaking. 0- Saved to memory. When the device energised, counting become from saved actual value. 1- Unsaved to memory. When the device energised, counting become from "0".
PRO-23	Slave Address for serial communication bus. Adjustable from 1 to 247. The parameter value is "1" for single device on the serial communication bus.
PRO-24	Configuration for MODBUS protocol. 0- MODBUS protocol is ASCII . 1- MODBUS protocol is RTU (Binary) .
PRO-25	Parity: 0-None, 1-Even, 2-Odd
PRO-26	Baud Rate: 0-1200 Bps, 1-2400 Bps, 2-4800 Bps, 3-9600 Bps, 4-19200 Bps
PRO-27	Stop Bits: 0- 1 Stop bit, 1- 2 Stop bit
PRO-28	Protection for RESET, SET-1 and SET-2 buttons on the front panel. The parameter is adjustable 0 to 5. 0-Non protection. All buttons are active. 1-Only protection for RESET button is active. 2-Protection for SET1 and SET2 buttons are active. 3-Protection for SET1, SET2 and RESET buttons are active. 4-Only protection for SET1 button is active. 5-Only protection for SET2 button is active.

	FREQUENCYMETER and TACHOMETER PARAMETERS:
PRO-03	Configuration for measurement method. 0- Counts per turn 1- Counts per time period.
PRO-04	Contact Bounce for electrical noise. Adjustable from 0 to 250 milliseconds.
PRO-07	This parameter is used when PRO-03=0 (counts per turn method). "Time-out" period can be set by this parameter (1 to 99 seconds). Actual counting value display will be have "000000" value if elapsed time is greater than the value is set in this parameter.
PRO-08	Measuring Period: This parameter is used when PRO-03=1 (counts per time period method). The time period for measurement can be set by this parameter (PRO-08=00.0 to 99.9 seconds).
PRO-09	Out-1 Function: 0- Latched; 1- Non-latched with hysteresis; 2- Alarm out
PRO-10	Out-2 Function: 0- Latched; 1- Non-latched with hysteresis
PRO-11	Output-1 Alarm Functions (If Pro-09=2 this parameter is active) 0-High alarm 1-Low alarm 2-High deviation alarm 3-Low deviation alarm 4-Deviation band alarm
PRO-12	Hysteresis for Out-1; Adjustable from 0 to 50000.
PRO-13	Hysteresis for Out-2; Adjustable from 0 to 50000.
PRO-14	Output Function for module-1 0- Normally non-energised 1- Normally energised
PRO-15	Output Function for module-2 0- Normally non-energised 1- Normally energised
PRO-16	Energising time for Module-1. Adjustable from 0000.00 to 0099.99 seconds. Refer to "Output Functions" for detail.
PRO-17	Energising time for Module-2. Adjustable from 0000.00 to 0099.99 seconds. Refer to "Output Functions" for detail.
PRO-18	Configuration for enabling the output functions; 0-When the unit is energized. (Power-up) 1-When the measured value reaches the SV1 value. 2-When the measured value reaches the Sv2 value.
PRO-20	Decimal point position of the display. 0 - 000000, 1 - 00000.0, 2 - 0000.00, 3 - 000.000, 4 - 00.0000
PRO-23	Slave Address for serial communication bus. Adjustable from 1 to 247. The parameter value is "1" for single device on the serial communication bus.
PRO-24	Configuration for MODBUS protocol. 0- MODBUS protocol is ASCII . 1- MODBUS protocol is RTU (Binary) .
PRO-25	Parity; 0-None, 1-Even, 2-Odd
PRO-26	Baud Rate; 0-1200 Bps , 1-2400 Bps, 2-4800 Bps, 3-9600 Bps, 4-19200 Bps
PRO-27	Stop Bits; 0- 1 Stop bit, 1- 2 Stop bit
PRO-28	Protection for RESET, SET-1 and SET-2 buttons on the front panel. The parameter is adjustable 0 to 5. 0-Non protection. All buttons are active. 1-Only protection for RESET button is active. 2-Protection for SET1 and SET2 buttons are active. 3-Protection for SET1, SET2 and RESET buttons are active. 4-Only protection for SET1 button is active. 5-Only protection for SET2 button is active.
PRO-29	Coefficient-1; (1 to 9999)
PRO-30	Coefficient-2; (1.000 to 99.9999)


	CHRONOMETER PARAMETERS:
PRO-02	Chronometer function and signal inputs 0- Total period measurement (ChA input) 1- Total pulse time measurement (ChA input) 2- Sum of the measured time period between the rising edges of ChA and ChB signals.
PRO-04	Contact Bounce for electrical noise. Adjustable from 0 to 250 milliseconds.
PRO-05	This parameter time base for Timer and Counter Mode. 0- From 00 hour 00 minute to 99 hours 59 minutes 1- From 00 minute to 00 second 99 minutes 59 seconds 2- From 00 second 00 millisecond to 99 seconds 99 milliseconds 3- From 00 hour 00 minute to 23 hours 59 minutes 4- From 000.00 hour to 999.99 hours 5- From 000.00 minute to 999.99 minutes 6- From 000.00 second to 999.99 seconds
PRO-06	Configuration for output functions. Refer to "Output Functions" for detail.
PRO-14	Output Function for module-1 0- Normally non-energised 1- Normally energised
PRO-15	Output Function for module-2 0- Normally non-energised 1- Normally energised
PRO-16	Energising time for Module-1. Adjustable from 0000.00 to 0099.99 seconds. Refer to "Output Functions" for detail.
PRO-17	Energising time for Module-2. Adjustable from 0000.00 to 0099.99 seconds. Refer to "Output Functions" for detail.
PRO-19	Selection counting direction. 0- 0 to PRESET 1- PRESET to 0
PRO-21	It's determinates, actual value on the display saved or unsaved to memory when the energy breaking. 0- Saved to memory. When the device energised, counting become from saved actual value. 1- Unsaved to memory. When the device energised, counting become from "0".
PRO-23	Slave Address for serial communication bus. Adjustable from 1 to 247. The parameter value is "1" for single device on the serial communication bus.
PRO-24	Configuration for MODBUS protocol. 0- MODBUS protocol is ASCII . 1- MODBUS protocol is RTU (Binary) .
PRO-25	Parity: 0-None, 1-Even, 2-Odd
PRO-26	Baud Rate: 0-1200 Bps, 1-2400 Bps, 2-4800 Bps, 3-9600 Bps, 4-19200 Bps
PRO-27	Stop Bits: 0- 1 Stop bit, 1- 2 Stop bit
PRO-28	Protection for RESET, SET-1 and SET-2 buttons on the front panel. The parameter is adjustable 0 to 5. 0-Non protection. All buttons are active. 1-Only protection for RESET button is active. 2-Protection for SET1 and SET2 buttons are active. 3-Protection for SET1, SET2 and RESET buttons are active. 4-Only protection for SET1 button is active. 5-Only protection for SET2 button is active.

4.4 Output Functions:

Output function - 0 (Manual Reset)


Counter, Totalizer Counter
Timer, Chronometer

Counting Direction : 0 → P (Counting to upwards)



When the actual value reaches SET1 value, OUT1 becomes active. If Out1 pulse time is "0", OUT1 doesn't change position until reset input becomes active. If Out1 pulse time isn't "0", at the end of this time OUT1 becomes inactive. When the actual value reaches SET2 value, OUT2 becomes active. Counting continues up to SET2 value.

Counting Direction : P → 0 (Counting to downwards)




When the actual value reaches SET1 value, OUT1 becomes active. If Out1 pulse time is "0", OUT1 doesn't change position until reset input becomes active. If Out1 pulse time isn't "0", at the end of this time OUT1 becomes inactive.

When the actual value reaches "0", OUT2 becomes active. Counting continues under "0".

Output function - 1 (Manual Reset)

Counter, Totalizer Counter
Timer, Chronometer


Counting Direction : 0 → P (Counting to upwards)



When the actual value reaches SET1 value, OUT1 becomes active. If Out1 pulse time is "0", OUT1 doesn't change position until reset input becomes active. If Out1 pulse time isn't "0", at the end of this time OUT1 becomes inactive.

When the actual value reaches SET2 value, OUT2 becomes active. Counting doesn't continue up to SET2 value.

Counting Direction : P → 0 (Counting to downwards)




When the actual value reaches SET1 value, OUT1 becomes active. If Out1 pulse time is "0", OUT1 doesn't change position until reset input becomes active. If Out1 pulse time isn't "0", at the end of this time OUT1 becomes inactive.

When the actual value reaches "0", OUT2 becomes active. Counting doesn't continue lower to "0".

Output function - 2 (Manual Reset)

Counter, Totalizer Counter
Timer, Chronometer


Counting Direction : 0 → P (Counting to upwards)



When the actual value reaches SET1 value, OUT1 becomes active. If Out1 was selected periodical, at the end of this time OUT1 changes position. If Out1 was selected indefinite, OUT1 changes position related to OUT2 or reset input. When the actual value reaches SET2 value, OUT2 becomes active. Counting continues until reset input becomes active. If Out2 was selected periodical, at the end of this time OUT2 changes position.

This condition, if OUT1 is active, OUT1 and OUT2 becomes inactive together.

Counting Direction : P → 0 (Counting to downwards)




When the actual value reaches SET1 value, OUT1 becomes active. If Out1 was selected periodical, at the end of this time OUT1 changes position. If Out1 was selected indefinite, OUT1 changes position related to OUT2 or reset input. When the actual value reaches "0", OUT2 becomes active. Counting continues until reset input becomes active. If OUT2 was selected periodical, at the end of this time OUT2 changes position.

This condition, if OUT1 is active, OUT1 and OUT2 becomes inactive together.

Output function - 3 (Automatic Reset)


Counter, Totalizer Counter
Timer, Chronometer

Counting Direction : 0 → P (Counting to upwards)



When the actual value reaches SET1 value, OUT1 becomes active. If OUT1 was selected periodical, at the end of this time OUT1 changes position. If OUT1 was selected indefinite, OUT1 changes position related to OUT2 or RESET input. When the actual value reaches SET2 value, OUT2 becomes active and actual value resets. If OUT2 was selected periodical, at the end of this time OUT2 changes position. This condition, if OUT1 is active, OUT1 and OUT2 becomes inactive together.



Counting Direction : P --> 0 (Counting to downwards)



When the actual value reaches SET1 value, OUT1 becomes active. If OUT1 was selected periodical, at the end of this time OUT1 changes position. If Out1 was selected indefinite, OUT1 changes position related to OUT2 or RESET input. When the actual value reaches "0", OUT2 becomes active. SET2 value appoints to actual value. If OUT2 was selected periodical, at the end of this time OUT2 changes position. This condition, if OUT1 is active, OUT1 and OUT2 becomes inactive together. If Out2 was selected indefinite, OUT2 is active until the RESET input becomes active.

Output function - 4 (Automatic Reset) Counter, Totalizer Counter Timer, Chronometer



Counting Direction : P --> 0 (Counting to downwards)



When the actual value reaches SET1 value, OUT1 becomes active. If OUT1 was selected periodical, at the end of this time OUT1 changes position. If Out1 was selected indefinite, OUT1 changes position related to Out2 or reset input. When the actual value reaches "0", OUT2 becomes active and counting stops. If OUT2 was selected periodical, at the and of this time OUT2 becomes inactive and SET2 value appoints to actual value.



Output function - 5 (Automatic Reset) Counter, Totalizer Counter Timer, Chronometer

Counting Direction : 0 --> P (Counting to upwards)





When the actual value reaches SET1 value, OUT1 becomes active. If OUT1 was selected periodical, at the end of this time OUT1 changes position. If Out1 was selected indefinite, OUT1 changes position related to OUT2 or RESET input. When the actual value reaches SET2 value, OUT2 becomes active and counting stops. If OUT2 was selected periodical, at the end of this time actual value resets and OUT2 becomes inactive.

Counting Direction : 0 --> P (Counting to upwards)





When the actual value reaches SET1 value, OUT1 becomes active. If OUT1 was selected periodical, at the end of this time OUT1 changes position. If Out1 was selected indefinite, OUT1 changes position related to OUT2 or RESET input. When the actual value reaches SET2 value, OUT2 becomes active and actual value becomes "0". When the Out2 is active, counting is continues but actual value display shows SET2 value.

Counting Direction : P → 0 (Counting to downwards)



When the actual value reaches SET1 value, OUT1 becomes active. If Out1 was selected periodical, at the end of this time OUT1 changes position. If Out1 was selected indefinite, OUT1 changes position related to Out2 or reset input. When the actual value reaches "0", OUT2 becomes active and actual value makes equal to SET2 value. When the Out2 is active, counting is continues but actual value display shows "0".

Counting Direction : P → 0 (Counting to downwards)





When the actual value reaches SET1 value, OUT1 becomes active. If Out1 was selected periodical, at the end of this time OUT1 changes position. If Out1 was selected indefinite, OUT1 changes position related to Out2 or reset input. When the actual value reaches "0", OUT2 becomes active and counting stops. If Out2 was selected periodical, at the end of this time OUT2 becomes inactive and SET2 appoints to actual value.

Output function - 6 (Automatic Reset) Counter, Totalizer Counter Timer, Chronometer


Output function -7 Counter and Totalizer Counter

Counting Direction : 0 → P (Counting to upwards)




When the actual value reaches SET1 value, OUT1 becomes active. If Out1 was selected periodical, at the end of this time OUT1 changes position. If Out1 was selected indefinite, OUT1 changes position related to Out2 or reset input. When the actual value reaches SET2 value, OUT2 becomes active and counting stops. If Out2 was selected periodical, at the end of this time OUT2 becomes inactive and actual value resets.

Counting Direction : 0 → P (Counting to upwards)




If actual value is equal or bigger than the SET1 value, OUT1 becomes active. If actual value is less than the SET1 value, OUT1 becomes inactive. If actual value is equal or bigger than the SET2 value, OUT2 becomes active. If actual value is less than the SET2 value, OUT2 becomes inactive

Counting Direction : P → 0 (Counting to downwards)



If actual value is equal or less than the SET1 value, OUT1 becomes active. If actual value is bigger than the SET1 value, OUT1 becomes inactive. If actual value is equal or less than "0", OUT2 becomes active. If actual value is bigger than the "0", OUT2 becomes inactive.

Counting Direction : 0 --> P (Counting to upwards)




When the actual value is equal or bigger than the SET1 value, the OUT1 becomes active. If the Out1 was selected periodical, Out1 becomes inactive at the end of the determined time. If the output was selected indefinite, the output becomes inactive when the actual value reaches to SET2 value.

When the actual value reaches to SET2 value, actual value becomes "0" and OUT2 becomes active. OUT2 is active when the actual value reaches to SET2 value.

NOTE: Out1 and Out2 outputs becomes active reverse.

Counting Direction : P --> 0 (Counting to downwards)




When the actual value is equal or less than the SET1 value, the OUT1 becomes active. If the Out1 was selected periodical, Out1 becomes inactive at the end of the determined time. If the output was selected indefinite, the output becomes inactive when the actual value reaches to "0".

When the actual value reaches to "0", SET2 appoints to actual value becomes SET2 value and OUT2 becomes active. OUT2 is active when the actual value reaches to "0".

NOTE: Out1 and Out2 outputs becomes active reverse.


CINCINNATI PRECISION MACHINERY 513-860-4133

Counting Direction : 0 --> P (Counting to upwards)




When the actual value reaches to SET2 value each time, Op2 becomes active during the period which is determined by Pro-17. There is a batch value which is incremented +1 when the Op2 becomes active each time. When the batch value reaches to SET1 value, Op1 is active until the RESET. Counting continuous until the RESET.

Counting Direction : 0 --> P (Counting to downwards)




When the actual value reaches to "0" each time, Op2 becomes active during the period which is determined by Pro-17. There is a batch value which is incremented +1 when the Op2 becomes active each time. When the batch value reaches to SET1 value, Op1 is active until the RESET. Counting continuous until the RESET.




When the actual value reaches to "0" each time, Op2 becomes active during the period which is determined by Pro-17. There is a batch value which is incremented +1 when the Op2 becomes active each time. When the batch value reaches to SET1 value, Op1 became active and the device resets the batch value. If the OP1 pulse time =0, the OP1 is always actives. If the OP1 pulse time !=0, Op1 is inactive when the end of time.

Output Functions of Frequency Meter and Tachometer


Out1 output function (Non-Latching Output)




Out2 output function (Non-Latching Output)



Out1 output function (Latching Output)




Out2 output function (Latching Output)




Out1 Alarm output function


High Alarm




Low Alarm




Deviation High Alarm



Deviation Low Alarm



Deviation Band Alarm



TECHNICAL SPECIFICATIONS:

TECHNICAL SPECIFICATIONS AND RATINGS

Equipment use	: Programmable Timer & Counter equipment
Housing & Mounting	: 72mm x 72mm x 86mm 1/8 DIN 43700 Plastic housing for panel mounting. Panel cut out is 69mm x 69mm.
Protection	: NEMA 4X (IP65 at front, IP20 at rear).
Weight	: Approximately 0.25 Kg.
Environmental rating	: Standard, indoor at an altitude of less than 2000 meters with non condensing humidity
Operating / Storage temperature	: -5 °C to +55 °C / -40 °C to +85 °C
Operating / Storage humidity	: 90 % max. (non condensing)
Installation overvoltage category	: III, Distribution level, fixed installation category
Pollution degree	: II, Normal office or workplace, non conductive pollution
Mode of operation	: Continuous
Supply voltage	: 85 to 264 VAC 50/60 Hz. 15 to 30 VAC 50/60 Hz., 18 to 36 VDC
Output Modules	: -EMO-700 Relay output module (5A@250Vac) -EMO-710 SSR driver output module (Max 20mA@18VDC) -EMO-720 Transistor output module (Maximum 40mA@18VDC)
Actual Counting Value Display	: 8 mm Red 6 digit LED display
Set Display	: 8 mm Green 6 digit LED display
LED indicators	: SV1(Set1 value), SV2(Set2 value), OP1/2(Control or Alarm output) LEDs

WARRANTY:

We warrant that the products will be free from defects in material and workmanship for 2 years from the date of bill.

The warranty above shall not apply for any failure caused by the use of the product not in line with the instructions reported on this manual.